



Signflute™ Corrugated Plastic Signs

VERTICAL FLUTE



Choose vertical flutes if using metal stands/spikes.

HORIZONTAL FLUTE



Choose horizontal flutes if installing on poles/stakes and fences, when using alternate fixings.

NOTE: If your signage includes eyelets, flute direction may not be important.

Flute Direction

Flute direction is particularly important for this size sign in case you are planning to use ground spikes with the order, if this is the case you will require vertical flutes. If this is not the case and you do not have a preference, we will print as per the greatest yield.

Election Signage

Flute direction is particularly important when the signs are attached to telegraph poles or vertical posts. In this case the flutes need to run horizontally to provide horizontal strength and ensure the signs do not "wrap" around the post in strong winds.

If you are in need of any support setting up your file, please contact our Customer Happiness Team on **1300 972 077** or by visiting www.easysigns.com.au